

Wireless


Once the router has booted you can connect to your wireless network from any suitable device.

The network name and password are printed on the back of the router along with a QR code to auto-connect.




Any questions?

If you have any further questions setting up, please visit <https://support.merula.net>
email support@merula.net
or call us on 01480 355 566




Quick Start Guide for Merula Broadband


Full Fibre & Ultrafast connections




Plug one end of the Ethernet cable to the blue WAN port of the router **1a**, the other end should connect to the ONT socket for fibre broadband or the Ethernet socket for your internet service.



For any device which connects directly to your router use an Ethernet cable and connect to one of the four yellow LAN ports **2**.



Plug in power supply and connect to router **3**.



Turn router power button on **4**.
Check LEDs are lit green on the front.
(This may take a few minutes)

or

ADSL and FTTC Connections

Connect the DSL cable to your router **1b**.
If your phone socket has a built in DSL (top), please plug the cable into the DSL socket. If not connect via the filter (bottom) included in the box.

